Instruction manual

Electric Gooseneck Kettle

Capacity:0.8L

Frequency:220-240V~50/60Hz 1000-1300W

PLEASE READ INSTRUCTION MANUAL BEFORE USAGE

KETTLE MAIN PARTS

1. Kettle cover

2. Handle

3.Heating base

4.Water Spout

SPECIAL FEATURES

- Elegant Shape & Leak-proof design for pour-over coffee and tea.
- Safety 304 food grade Stainless Steel preserves pure flavors.
- Ergonomic and counterbalanced handle provides a comfortable and sturdy grip.
- Easy to open and less the risk of steam outlet.
- 1200W fast boiling for brewing tea or coffee
- 360℃ rotational power base.
- Slender goose neck kettle Spout makes the water flow easier to control.
- 800ml (27 Oz) Capacity Pour-over brewing.
- Boil-Dry Protection & Automatic Shutoff.

KETTLE OPERATION

For first time using, it is recommended that you fill the kettle to the maximum level mark with fresh tap water, boil, and empty the kettle at least two times to clear the kettle of any dust or materials from the manufacturing process. Do not drink this water.

1. Remove the kettle from the base to fill it. Press the switch at the top of the handle to open the lid. Pour water into the kettle to the desired level, (no less than MINIMUM and no more than MAXIMUM) press the lid shut and place the kettle back on the base unit. CAUTION: Too little water may damage the heating element and too much water may cause water to splatter from the kettle.
2. Connect the plug into the power outlet, turn the kettle on by pressing the switch on-off. Ensure the kettle is positioned so the spout is facing away from you.
3. The kettle will automatically switch itself off once the water into a container or cup.
4. Lift the kettle from the base and pour the water into a container or cup.
5. The boiling process can be terminated at any time by lifting the kettle off the power base. **CAUTION**: Do not lift the lid during boiling.

CARE AND MAINTAINENCE

1. Do not attempt to dismantle the kettle or power base. There are no user serviceable parts. For service or repair, contact an authorized electrician.
2. To prolong the kettle's life, please clean the mineral deposits in the kettle regularly.
3. Always unplug from the plug socket and allow to cool down before cleaning.
4. Do not immerse the power cord, kettle or power base in water.
5. Do not use chemicals, steel wool, or abrasive cleaners to clean the outside of the kettle as these will scratch the surface and fade the outside color.
6. Periodical descaling is required. The interval of descaling depends on the hardness of water in your area and the frequency of using the kettle.
7. Fill the kettle with 0.5liter white vinegar and the remainder with water and allow to stand for at least one hour.
8. Empty the solution from the kettle. Wipe the remaining deposits with a damp cloth.

9. Fill the kettle with clean water, bring to boil and then discard the water. Repeat at least once or until no mineral deposits are left and the kettle will be ready to use.

Thanks for your choosing this electric goose-neck kettle. This appliance has been designed and manufactured to high standards of engineering and with proper use and care, as described in this leaflet, will give you years of useful service. Please read these instructions carefully.

GENERAL CARE AND SAFETY GUIDE

1. Read instructions carefully before using this kettle & keep them for future reference.
2. This appliance heats up when in use. To avoid burns, do net touch hot surfaces.
3. Do not use the kettle on a wet surface, or where it can fall or be pushed into water.
4. Do not reach for any appliance that has fallen into water. Switch off at the power outlet and unplug immediately.
5. Do not operate the kettle with a damaged cord, plug, after the kettle malfunctions or has been dropped or damaged in any manner. Return to a qualified electrician for examination, electrical or mechanical adjustment, service or repair.
6. This kettle is intended for household use only and not for commercial or industrial use. Do not use outdoors.
7. Use the kettle only as described in this manual. Any other use is not recommended by the manufacturer and may cause electric shock or injury.
8. Do not us abrasive cleaning products on this appliance. Clean with a damp cloth (not wet) rinsed in hot soapy water only. Always remove plug from the power outlet before cleaning.
9. Do not operate the kettle unless the element is fully immersed.
10. Do not remove the plug from the power outlet until the appliance has switched off.
11. Do not remove the plug from the power outlet by pulling flex-always grip the plug.
12. Do not allow the cord to come in contact with heated surfaces during operation.
13. Do not twist, kink or wrap the cord around the appliance, as this may cause the insulation to weaken and split.
14. Do not store the kettle while it is still hot.
15. This appliance is not intended for use by young children or infirm persons without supervision.
16. Young children should be supervised to ensure they do not play with the appliance.
17. If the supply cord is damaged. it must be replaced by a qualified electrical person in order to weaken and split.
18. Do not fill the kettle while positioned on its base. Dry off any water on the bottom of the kettle before placing on the power base.
19. Use the kettle only with the power base provided.
20. Do not use the kettle to heat anything other than water. Do not use any base unit other than the one supplied. The use of any accessory or attachment not recommended by the manufacturer may result in free, electrical shock or personal injury.
21. Do not insert any object into slots or holes of the kettle.

CAUTION: DO NOT OPERATE THE KETTLE ON AN INCLINED SURFACE. DO NOT MOVE THE KETTLE WHILE IN USE. DO NOT FILL ABOVE THE “MAX” MARKING AS BOILING WATER MAY BE EJECED CREATING A RISK OF BURNS.